





















Data Logging and Monitoring Pro

Hans-Petter Halvorsen, M.Sc.

Chart

Data

 2016-06-21 13:48:35

- T-102 
- Channel 1 
- Channel 2 
- Channel 3 
- Channel 4 
- Channel 5 
- Channel 6 
- Channel 7 
- Channel 8 
- Channel 9 
- Channel 10 
- Channel 11 
- Channel 12 
- Channel 13 
- Channel 14 
- Channel 15 

Data Logging and Monitoring

With this Data Logging and Monitoring App you can Log and Monitoring Data from a DAQmx DAQ Device from National Instruments. Examples of Such DAQ Devices are USB-6001, USB-6008, USB-6009, myDAQ, etc. You can log up till 32 Channels simultaneously (depending on the DAQ device you are using).

Logging Options:


- Log Data to File (*.lvm Files)
- Log Data to Microsoft SQL Server Database, either Locally or Remote. With this option you need to have access to the Database from this Computer.
- Log Data to a remote Data Cloud Service

You can use an existing SQL Server or install a new SQL Server either on this computer or in a network or Internet. Microsoft SQL Server Express can be downloaded for free on Internet.


Data Monitoring:

You can also use the "Data Dashboard for LabVIEW App" on iPad or Android devices in order to Monitor the Data you are Logging – either locally or via the Data Cloud Service

Data Logging and Monitoring Pro



Data Logging and Monitoring Pro





Get Help

Hans-Petter Halvorsen, M.Sc.

- User Guide Ctrl+H
- Video
- Data Dashboard for LabVIEW
- Home



















 2016-06-21 13:50:57

Chart Data



- T-102 
- Channel 1 
- Channel 2 
- Channel 3 
- Channel 4 
- Channel 5 
- Channel 6 
- Channel 7 
- Channel 8 
- Channel 9 
- Channel 10 
- Channel 11 
- Channel 12 
- Channel 13 
- Channel 14 
- Channel 15 




Monitoring

Hans-Petter Halvorsen, M.Sc.

Chart

Data


Open Separate Windows
for Charting and Data



Measurement Data

0,76	22,89
0,00	0,00
0,00	0,00
0,00	0,00
0,00	0,00
0,00	0,00
0,00	0,00
0,00	0,00
0,00	0,00

- T-102
- Channel 1
- Channel 2
- Channel 3
- Channel 4
- Channel 5
- Channel 6
- Channel 7
- Channel 8
- Channel 9
- Channel 10
- Channel 11
- Channel 12
- Channel 13
- Channel 14
- Channel 15



A Separate full-screen
Window for Plotting



Database

Hans-Petter Halvorsen, M.Sc.

SQL Server


- You can Log Data to Microsoft SQL Server Database, either Locally or Remote.
- With this option you need to have access to the Database from this Computer.
- If you want to log data to a SQL Server, you can use an existing SQL Server or Download SQL Server Express for free

SQL Script

Database.sql


When you have installed SQL Server, you need to run the “Database.sql” Script in order to create necessary Tables, etc.

Then Connect to the Database and you are ready:



SQL Server

The «Database.sql» script contains
Tables, Stored Procedures, Views, etc.
used by the Client.



Databases Settings

Device Settings Ctrl+D

Tag Settings Ctrl+T

Logging Settings Ctrl+L

28

Database Settings

Data Source Name
HANSPPH_LAPTOP\SQLEXPRESS

Database Name
DMM

User Name
sa

Password

OK Cancel

The Database Settings are stored in a Configuration File

You can change the Setting from the GUI or directly in the Configuration File



```
DAQSettings.ini - Notepad
File Edit Format View Help

[Device]
DeviceType = "USB-6001"
DeviceName = "USB-6001-1"
DAQmxName = "Dev5"
TerminalWiring = "RSE"

[Logging]
LoggingInterval = 1,000000
UseFilter = FALSE
FilterValue = 5,000000
LogToFile = FALSE
LogFolder = "/c/Temp"
UseRandomData = FALSE

[Chart]
XAxisFormat = FloatingPoint
ChartDataInput = EUData

[Database]
DSN = "HANSPPH_LAPTOP\\SQLEXPRESS"
Database = "DMM"
UserName = "sa"
Password = "*****"



[CloudService]
LogToCloudService = FALSE
CloudServiceUrl = "http://127.0.0.1:8001/DataCloudws"
```



Configuration


Hans-Petter Halvorsen, M.Sc.

Device Settings



The Device Settings are stored in a Configuration File

You can change the Setting from the GUI or directly in the Configuration File



```
DAQSettings.ini - Notepad
File Edit Format View Help
[Device]
DeviceType = "USB-6001"
DeviceName = "USB-6001-1"
DAQmxName = "Dev5"
TerminalWiring = "RSE"

[Logging]
LoggingInterval = 1,000000
UseFilter = FALSE
FilterValue = 5,000000
LogToFile = FALSE
LogFolder = "/c/Temp"
UseRandomData = FALSE

[Chart]
XAxisFormat = FloatingPoint
ChartDataInput = EUData

[Database]
DSN = "HANSPH_LAPTOP\\SQLEXPRESS"
Database = "DMM"
UserName = "sa"
Password = "*****"

[CloudService]
LogToCloudService = FALSE
CloudServiceUrl = "http://127.0.0.1:8001/DataCloudws"
```

Tag Settings

Tag Settings

Tags for Device "USB-6001-1":

TagId	Tag Name	Tag Type	Channel	Vmin	Vmax	Unit	EUmin	EUmax
7	T-102	Temperature	Dev5/ai0	0	1	Celsius	0	30

+ Create ⚙ Edit ↻ Link - Remove

■ Exit

Add Tag

Tag Name

Tag Type

DAQmx Physical Channel

Vmin

Vmax

Unit

EUmin

EUmax

OK Cancel

Edit Tag

Tag Name

Tag Type

DAQmx Physical Channel

Vmin

Vmax

Unit



EUmin

EUmax

OK Cancel


The Tag Settings are stored in the Database

Logging Settings



The Logging Settings are stored in a Configuration File

You can change the Setting from the GUI or directly in the Configuration File



```
DAQSettings.ini - Notepad
File Edit Format View Help

[Device]
DeviceType = "USB-6001"
DeviceName = "USB-6001-1"
DAQmxName = "Dev5"
TerminalWiring = "RSE"

[Logging]
LoggingInterval = 1,000000
UseFilter = FALSE
FilterValue = 5,000000
LogToFile = FALSE
LogFolder = "/c/Temp"
UseRandomData = FALSE

[Chart]
XAxisFormat = FloatingPoint
ChartDataInput = EUData

[Database]
DSN = "HANSPH_LAPTOP\\SQLEXPRESS"
Database = "DMM"
UserName = "sa"
Password = "*****|"

[CloudService]
LogToCloudService = FALSE
CloudServiceUrl = "http://127.0.0.1:8001/DataCloudws"
```



Web Service

Hans-Petter Halvorsen, M.Sc.

Data Web Service

The Port is default “8002”, but can be changed in a Configuration File



<IP Address>:<Port>/DataWS/<Web Service Method>




“DataWS” is the Name of the existing Web Service

AvailableWeb Service Methods

- **GetChannel?Channel={value}**
 - Gets the Current Value for the spesific Channel
- **GetData**
 - Get the Current Values for All Channels


Web Service Example



```
<?xml version="1.0"?>
- <Response>
  - <Terminal>
    <Name>DataChannel</Name>
    <Value>23.38964619557373</Value>
  </Terminal>
</Response>
```

<IP Address>:<Port>/GetChannel?Channel=1


Web Service Example



```
<?xml version="1.0"?>  
- <Response>  
  - <Terminal>  
    <Name>DataChannel</Name>  
    <Value>90.02823087037541</Value>  
  </Terminal>  
</Response>
```

<IP Address>:<Port>/GetChannel?Channel=2

Web Service Example



```
<?xml version="1.0"?>
- <Response>
  - <Terminal>
    <Name>Data</Name>
    - <Value>
      <DimSize>2</DimSize>
      <Name>ChannelValue</Name>
      <Value>23.65980660310015</Value>
      <Name>ChannelValue</Name>
      <Value>90.07968999561854</Value>
    </Value>
  </Terminal>
</Response>
```

<IP Address>:<Port>/GetData



Data Dashboard for LabVIEW

Hans-Petter Halvorsen, M.Sc.

iPad

6:11 PM

64%

Dashboards

New Dashboard

Production Monitor


System State

abc

Timer



Process Variables



Test Name

UUT

Start

Stop

Reset

< Back

Indicators



LED



Gauge



Graph

abc

String



List Box



XY Graph

123

Numeric



Chart


Fan On/Off



Fan Speed



Data Dashboard for LabVIEW



- You can also use the "Data Dashboard for LabVIEW App" on iPad or Android devices in order to Monitor the Data you are Logging.
- <https://www.ni.com/mobile/>

AvailableWeb Service Methods

- **GetChannel?Channel={value}**
 - Gets the Current Value for the spesific Channel
- **GetData**
 - Get the Current Values for All Channels



Data Cloud Service

Hans-Petter Halvorsen, M.Sc.

Data Cloud Service


- In addition to Log Data to a File or a Database, you can also Log Data to a remote “Data Cloud Service”.
- You can download the “Data Cloud Service” from my Web Site.
- Then you can install it on a computer/server in your Local Network or in the Cloud
- The Communication between the client and the Data Cloud is done by a Web Service API

Data Cloud Service

In addition to installing the Data Cloud Service, the Data Cloud Storage, which is just a SQL Server Database with Tables, Stored Procedures, Views, etc.

When you have installed SQL Server, you need to run the “Database.sql” Script in order to create necessary Tables, etc.

Finally, you can start the Data Cloud Service, which is actually a LabVIEW Web Service.



Logging Settings



Logging Interval [s]

Use Random Data

Use Lowpass Filter


Tf [s]

Logging Data to File

Log Folder

Logging Data to Cloud Service

Data Cloud Service Url



Hans-Petter Halvorsen, M.Sc.



University College of Southeast Norway

www.usn.no

E-mail: hans.p.halvorsen@hit.no

Blog: <http://home.hit.no/~hansha/>

